


## Freio de Arame Exterior em Aço (DIN7993)| Tabelas




Código	Descrição (d1 x d7)	d1	d3	d2	e
FR.7993E.004	FREIO DE ARAME EXTERIOR (7993) AÇO 004 x 0.80	4	3,1	3,2	1,0
FR.7993E.005	FREIO DE ARAME EXTERIOR (7993) AÇO 005 x 0.80	5	4,1	4,2	1,0
FR.7993E.006	FREIO DE ARAME EXTERIOR (7993) AÇO 006 x 0.80	6	5,1	5,2	1,0
FR.7993E.007	FREIO DE ARAME EXTERIOR (7993) AÇO 007 x 0.80	7	6,1	6,2	2,0
FR.7993E.008	FREIO DE ARAME EXTERIOR (7993) AÇO 008 x 0.80	8	7,1	7,2	2,0
FR.7993E.010	FREIO DE ARAME EXTERIOR (7993) AÇO 010 x 0.80	10	9,1	9,2	2,0
FR.7993E.012	FREIO DE ARAME EXTERIOR (7993) AÇO 012 x 1.00	12	10,8	11,0	3,0
FR.7993E.014	FREIO DE ARAME EXTERIOR (7993) AÇO 014 x 1.00	14	12,8	13,0	3,0
FR.7993E.016	FREIO DE ARAME EXTERIOR (7993) AÇO 016 x 1.60	16	14,2	14,4	3,0
FR.7993E.018	FREIO DE ARAME EXTERIOR (7993) AÇO 018 x 1.60	18	16,2	16,4	3,0
FR.7993E.020	FREIO DE ARAME EXTERIOR (7993) AÇO 020 x 2.00	20	17,7	18,0	3,0
FR.7993E.022	FREIO DE ARAME EXTERIOR (7993) AÇO 022 x 2.00	22	19,7	20,0	3,0
FR.7993E.024	FREIO DE ARAME EXTERIOR (7993) AÇO 024 x 2.00	24	21,7	22,0	3,0
FR.7993E.025	FREIO DE ARAME EXTERIOR (7993) AÇO 025 x 2.00	25	22,7	23,0	3,0
FR.7993E.026	FREIO DE ARAME EXTERIOR (7993) AÇO 026 x 2.00	26	23,7	24,0	3,0
FR.7993E.028	FREIO DE ARAME EXTERIOR (7993) AÇO 028 x 2.00	28	25,7	26,0	3,0
FR.7993E.030	FREIO DE ARAME EXTERIOR (7993) AÇO 030 x 2.00	30	27,7	28,0	3,0
FR.7993E.032	FREIO DE ARAME EXTERIOR (7993) AÇO 032 x 2.50	32	29,1	29,5	4,0
FR.7993E.035	FREIO DE ARAME EXTERIOR (7993) AÇO 035 x 2.50	35	32,1	32,5	4,0
FR.7993E.038	FREIO DE ARAME EXTERIOR (7993) AÇO 038 x 2.50	38	35,1	35,5	4,0
FR.7993E.040	FREIO DE ARAME EXTERIOR (7993) AÇO 040 x 2.50	40	37,1	37,5	4,0
	FREIO DE ARAME EXTERIOR (7993) AÇO 042 x 2.50	42	39,0	39,5	4,0
FR.7993E.045	FREIO DE ARAME EXTERIOR (7993) AÇO 045 x 2.50	45	42,0	42,5	4,0
FR.7993E.048	FREIO DE ARAME EXTERIOR (7993) AÇO 048 x 2.50	48	45,0	45,5	4,0
FR.7993E.050	FREIO DE ARAME EXTERIOR (7993) AÇO 050 x 2.50	50	47,0	47,5	4,0
FR.7993E.055	FREIO DE ARAME EXTERIOR (7993) AÇO 055 x 3.20	55	51,1	51,8	4,0
FR.7993E.060	FREIO DE ARAME EXTERIOR (7993) AÇO 060 x 3.20	60	56,1	56,8	4,0
FR.7993E.065	FREIO DE ARAME EXTERIOR (7993) AÇO 065 x 3.20	65	61,1	61,8	4,0
FR.7993E.070	FREIO DE ARAME EXTERIOR (7993) AÇO 070 x 3.20	70	66,0	66,8	5,0
FR.7993E.075	FREIO DE ARAME EXTERIOR (7993) AÇO 075 x 3.20	75	71,0	71,8	5,0
FR.7993E.080	FREIO DE ARAME EXTERIOR (7993) AÇO 080 x 3.20	80	76,0	76,8	5,0
FR.7993E.085	FREIO DE ARAME EXTERIOR (7993) AÇO 085 x 3.20	85	81,0	81,8	5,0
FR.7993E.090	FREIO DE ARAME EXTERIOR (7993) AÇO 090 x 3.20	90	86,0	86,8	5,0
FR.7993E.095	FREIO DE ARAME EXTERIOR (7993) AÇO 095 x 3.20	95	91,0	91,8	5,0
	FREIO DE ARAME EXTERIOR (7993) AÇO 100 x 3.20	100	95,8	96,8	5,0
FR.7993E.105	FREIO DE ARAME EXTERIOR (7993) AÇO 105 x 3.20	105	100,8	101,8	5,0

# FREIOS DE SEGURANÇA

CATÁLOGO DE FREIOS DE SEGURANÇA

HM032-01 | 6ª Edição | Abril 2021

## Freio de Arame Exterior em Aço (DIN7993) | Tabelas



Código	Descrição (d1 x d7)	d1	d3	d2	e
FR.7993E.110	FREIO DE ARAME EXTERIOR (7993) AÇO 110 x 3.20	110	105,8	106,8	5,0
	FREIO DE ARAME EXTERIOR (7993) AÇO 115 x 3.20	115	110,8	111,8	5,0
	FREIO DE ARAME EXTERIOR (7993) AÇO 120 x 3.20	120	115,8	116,8	5,0
	FREIO DE ARAME EXTERIOR (7993) AÇO 125 x 3.20	125	120,8	121,8	5,0