



## 30.KIT.03

70 un

				
10.001.10 Lubrificador 06 x 100 10un	10.001.14 Lubrificador 08 x 100 10un	10.001.18 Lubrificador 10 x 100 10un	10.001.38 Lubrificador 1/8" GAS 10un	10.002.10 Lubrificador 45° 06 x 100 5un
				
10.002.14 Lubrificador 45° 08 x 100 5un	10.002.18 Lubrificador 45° 10 x 100 5un	10.003.10 Lubrificador 90° 06 x 100 5un	10.003.14 Lubrificador 90° 08 x 100 5un	10.003.18 Lubrificador 90° 10 x 100 5un